



Velina

Installation Instructions

Velina is a unique collection of non-woven cellulose textured wallcoverings and subtle variations in color should be expected throughout the bolts. Although extreme care is taken during the manufacturing process, these subtleties are inherent characteristics of the products natural intrinsic beauty, and should not be considered flaws or imperfections.

Check Before Cutting:

The first step you should take is to confirm that all the materials you have received match what was ordered and are correct regarding the pattern number, color, and width. Before proceeding with the installation, make a final inspection to verify the run numbers of each bolt and check for any manufacturing defects in the material. Take a moment to make sure that you have sufficient material on hand to complete this job. Each full bolt of goods will be 11 yards in length. This product may exhibit subtle color variations between the samples and the actual delivered materials as well as between different runs/lots. These variations are to be expected as they are inherent characteristics of the wallcovering and cannot be avoided.

NO CREDIT WILL BE ALLOWED FOR CUTTING OR INSTALLING INCORRECT PATTERNS OR COLORWAYS. Cut material cannot be returned.

Application of materials is interpreted as acceptance of the material and conditions of the installation. Should you have any questions regarding the material or installation procedures, please contact your Winfield Design Sales Representative or our Customer Service Department at 1-800-486-6800 before proceeding with the installation.

Surface Preparation:

Ensure surfaces are dust free, smooth, dry, firm and uniformly colored or primed. Do not install over non-porous surfaces. Previously painted walls may be wiped down with Tri Sodium Phosphate to remove any grease or oil. Glossy paint should be dulled by sanding. Never install these materials over new plaster or un-primed walls. It is best to prime all surfaces with an appropriate high quality acrylic wallcovering primer. All surfaces to be installed should be tested by the installer to determine suitable adherence of existing coatings.

Trimming:

Bolts are shipped with pre-trimmed edges and do not require additional cutting.

Adhesive:

You **MUST** use a quality grade of heavy-duty premixed clear vinyl adhesive with a low water content. Do not dilute. **Apply an even coat of adhesive to the back of the wallcovering.** Allow the adhesive to become tacky before applying wallcovering. Never allow the adhesive to get on the front of the material. Do not use a pasting machine when hanging this product.

Installation:

Wallcovering shall be installed by professional experienced workers and contractors in strict accordance with these instructions.

Use strips in exact order as they are cut from the roll. Cut material in consecutive bolt sequence, as marked on the end of each wrapper. The material may be applied immediately without booking. Do not fold the sheets, as the material can crease as a result. The manufacture ships this material pre-trimmed at 30" wide. All Velina patterns should be straight hung; **DO NOT REVERSE THE STRIPS.**

Apply material to wall using a soft bristle smoothing brush. When smoothing, first butt align one pretrimmed factory edge and then smooth with vertical strokes across the width to the opposite edge. To avoid trapping air bubbles, use an oval seam roller to set seams. Avoid paste on the surface of the wallcovering. Any paste marks should be removed immediately with a sponge and clean water – gently dabbing the area.

Test Hanging:

Test hang three strips and carefully review materials and application. If satisfactory, continue the installation. If not, please contact your Winfield Design Sales Representative or our Customer Service Department at 1-800-486-6800 before proceeding with the installation.

Winfield Design assumes no responsibility for the installation of material beyond three strips. Under no circumstances will Winfield Design be responsible for labor.

The above information is intended only as a guideline; the installer has final responsibility for proper installation.

Winfield Design

1200 Arthur Avenue
Elk Grove, Illinois 60007
tel 800.486.6800
fax. 800.430.6807

www.winfielddesign.com